




LumiTap Quickstart




Power Connection




Release cable retention



Connect USB cable




Fasten cable retention



Seat cable in guide


Game Selection



Switch between games




(Re-) start game




Interrupt ongoing game: press and hold key

Game Administration


...and let's go!




Connect to LumiTap



Username: admin



Common settings



(De-) activate games



Game Guides


<https://lumitap.info/games/>

Additional Guides





<https://lumitap.info/guides/>



Connect to LumiTap



For game **administration** and **live** view, you can connect any devices via **Wi-Fi** (LumiTap AA:BB:CC:XX:YY:ZZ) to your LumiTap.
The LumiTap **web app** is then accessible at **http://lumitap.local** using any web browser.
Wi-Fi **access credentials**: press and hold both ◀▶ buttons.





Connect to WLAN


Cancel dialog:

"Use Without Internet"

http://lumitap.local



Live View



Choose: 4 different fullscreen views

Live screen

Game guide



Device Administration: Setup external WLAN

The first screen shows the LumiTap home interface with a 'Welcome!' message and a 'Sign in' button. A white arrow points to the 'Sign in' button. The second screen shows the 'Sign in' dialog with fields for 'Username' (pre-filled with 'device') and 'Password'. A white arrow points to the 'Sign in' button. The third screen shows the 'External WLAN' setup screen with a 'Connect' toggle switch. A white arrow points to the 'Connect' toggle. The fourth screen shows the 'External WLAN' setup screen with the 'Connect' toggle turned on. A white arrow points to the 'Connect' toggle.

Connect to LumiTap.

Username: device

Enter credentials and enable connection.

LumiTap connects to external WLAN.

Device Administration: Update LumiTap

The first screen shows the 'External WLAN' setup screen with the 'Connect' toggle turned on. A white arrow points to the 'Connect' toggle. The second screen shows the 'Software Updates' screen with a list of updates. A white arrow points to the 'INSTALL' button for the latest update. The third screen shows the 'Software Updates' screen with the 'INSTALL' button highlighted. A white arrow points to the 'INSTALL' button. The fourth screen shows the 'Software Updates' screen with the 'INSTALL' button highlighted. A white arrow points to the 'INSTALL' button. The fifth screen shows the 'Software Updates' screen with the 'INSTALL' button highlighted. A white arrow points to the 'INSTALL' button. The sixth screen shows the 'Software Updates' screen with the 'INSTALL' button highlighted. A white arrow points to the 'INSTALL' button. The seventh screen shows the 'Software Updates' screen with the 'INSTALL' button highlighted. A white arrow points to the 'INSTALL' button.

Setup external WLAN.

Scroll down to list Updates.

Confirm to install LumiTap update.

Wait for update to finish.

LumiTap restarts automatically.

If asked after restart: sign in again.

Update was installed.